


Technical Training

**Aerospace Ground Equipment Specialist
Power Production Specialist
Refrigeration Specialist**

**MEP 805/815B, 30kW Generator Set (TQG)
Tables, Flow Charts and Diagrams**




April 2003

**Air Force Engineering and Technical Services (AFETS)
3rd Combat Communications Support Squadron
Tinker Air Force Base, Oklahoma 73145-8600**

Designed for AFETS Course Use Only


DO NOT USE ON THE JOB



LEGEND:

- 1. COMMUNICATION PORT
 - 2. PARALLELING RECEPTACLE
 - 3. CONVENIENCE RECEPTACLE
 - 4. DCS CONTROL PANEL ASSEMBLY
 - 5. COMPUTER INTERFACE MODULE
 - 6. AIR CLEANER ASSEMBLY
 - 7. AC GENERATOR
 - 8. FUEL DRAIN VALVE
 - 9. FUEL TANK
 - 10. DEAD CRANK SWITCH
- (CONTINUED ON SHEET 2)

FIGURE 1-30. 30 KW GENERATOR SET COMPONENTS (SHEET 1 OF 2)



LEGEND:

(CONTINUED FROM SHEET 1)

- | | |
|---------------------------|---|
| 11. MUFFLER | 20. ENGINE |
| 12. RADIATOR | 21. BATTERY CHARGING ALTERNATOR |
| 13. FAN BELT | 22. DIPSTICK |
| 14. OIL DRAIN VALVE | 23. STARTER |
| 15. BATTERY (2) | 24. CRANKCASE BREATHER
FILTER ASSEMBLY |
| 16. SKID BASE | 25. FUEL FILTER/WATER ASSEMBLY |
| 17. NATO SLAVE RECEPTACLE | 26. LOAD OUTPUT TERMINAL BOARD |
| 18. WATER PUMP | 27. VOLTAGE RECONNECTION TERMINAL BOARD |
| 19. OIL FILTER | |

FIGURE 1-30. 30 KW GENERATOR SET COMPONENTS (SHEET 2 OF 2)

1.17 LOCATION AND DESCRIPTION OF MAJOR COMPONENTS.

NOTE

All locations (Figure 1-30) referenced herein are given facing the control box side (rear) of the generator set.

- 1.17.1 COMMUNICATION RECEPTACLE (1). The COMMUNICATION RECEPTACLE is used to connect a remote PC to the DCS control box to facilitate remote operation and monitoring of the generator set.
- 1.17.2 PARALLELING RECEPTACLE (2). The PARALLELING RECEPTACLE is used to connect the paralleling cable between two generator sets of the same size and mode to operate in parallel.
- 1.17.3 CONVENIENCE RECEPTACLE (3). The CONVENIENCE RECEPTACLE is a 120VAC receptacle use to operate small plug-in type equipment.
- 1.17.4 DCS Control Panel Assembly (4). The DCS control panel is located at the rear of the generator set and contains the CIM, switches, and connectors used to control and monitor generator set operation.
- 1.17.5 Computer Interface Module (CIM) (5). The CIM is located in the DCS control box and contains controls and indicators for operating the generator set.
- 1.17.6 Air Cleaner Assembly (6). The air cleaner assembly is located on the left side behind the AIR CLEANER ACCESS door. It consists of a dry-type, disposable paper filter and canister. The air cleaner assembly features a dust collector which traps large dust particles. The air cleaner assembly has a restriction indicator which will pop up during operation when the air cleaner requires servicing.
- 1.17.7 AC Generator (7). The AC generator is a single bearing, drip-proof, synchronous, brushless, three phase, air-cooled generator. The generator is coupled directly to the rear of the diesel engine.
- 1.17.8 Fuel Drain Valve (8). The fuel drain valve is located on the left side of the skid base. It allows personnel to drain the fuel tank for maintenance.
- 1.17.9 Fuel Tank (9). The 23 gallon (87.05 liter) fuel tank is located in the front of the generator set below the engine and between the skid base members. The fuel tank has sufficient capacity to enable the generator set to operate for at least 8 hours without refueling.
- 1.17.10 DEAD CRANK Switch (10). The DEAD CRANK switch is located in the engine compartment on the left side. The switch allows the engine to be turned over without starting for maintenance purposes.
- 1.17.11 Muffler (11). The muffler and exhaust tubing are connected to the turbocharger on the engine. The exhaust exits from the top of the generator set housing. Gases are exhausted upward.
- 1.17.12 Radiator (12). The radiator is located at the front of the generator set. It acts as a heat exchanger for engine coolant.
- 1.17.13 Fan Belt (13). The fan belt is located in the engine compartment on the front of the engine. The belt drives the fan, water pump, and battery charging alternator.
- 1.17.14 Oil Drain Valve (14). The oil drain valve is located at the front of the skid base. It allows personnel to drain engine oil for maintenance.

- 1.17.15 Batteries (15). Two batteries are located at the front of the generator set. The batteries are maintenance free, 12 volt type. After starting, the generator set is capable of operating with batteries removed. A diode, located behind the control panel, protects the generator set if the batteries are incorrectly connected.
- 1.17.16 Skid Base (16). The skid base supports the generator set. It has fork lift access openings and cross members for short distance movement. The skid base has provisions in the bottom for installation of the generator set on a trailer.
- 1.17.17 NATO SLAVE RECEPTACLE (17). The NATO SLAVE RECEPTACLE is located on the right side (front) of the generator set. It is a NATO receptacle used for remote battery connection.
- 1.17.18 Water Pump (18). The water pump is located on the front of the engine. The pump circulates engine coolant through the engine block and the radiator.
- 1.17.19 Oil Filter (19). The oil filter is located in the engine compartment on the left side. The filter removes impurities from engine oil.
- 1.17.20 Engine (20). The generator is powered by a four cylinder, four cycle, fuel injected, turbocharged, liquid-cooled diesel engine which occupies the front half of the generator set. The engine is also equipped with a fuel filter/water separator, oil filter, and air cleaner assembly. Protection devices automatically stop the engine during conditions of high coolant temperature, low oil pressure, no fuel, overspeed, and overvoltage.
- 1.17.21 Battery Charging Alternator (21). The battery charging alternator is located on the right side of the engine. It is capable of maintaining the batteries in a state of full charge in addition to providing the required 24 VDC control power.
- 1.17.22 Dipstick (22). The dipstick is located in the engine compartment on the left side. The dipstick shows the level of oil in the engine drain pan.
- 1.17.23 Starter (23). The starter is located on the left side of the engine. The electric cranking motor mechanically engages the engine flywheel in order to start the diesel engine.
- 1.17.24 Crankcase Breather Filter Assembly (24). The crankcase breather filter assembly is located in the engine compartment on the right side. The filter element removes oil particles and contaminants from air as it passes from the crankcase to engine air intake.
- 1.17.25 Fuel Filter/Water Separator (25). The fuel filter/water separator is located in the engine compartment on the right side. The element removes impurities and water from the diesel fuel.
- 1.17.26 Load Output Terminal Board (26). The load output terminal board is located on the right side (rear) of the generator set. Four AC output terminals are located on the board. They are marked L1, L2, L3, and L0. A fifth terminal, marked GND, is located next to the output terminals and serves as equipment ground for the generator set. A removable, solid copper bar is connected between the L0 and GND terminals.
- 1.17.27 Voltage Reconnection Terminal Board (27). The voltage reconnection terminal board is located on the right side (rear) of the generator set. The board allows reconfiguration from 120/208 to 240/416 VAC output.

TABLE 1-1. TABULATED DATA

	MEP-805B	MEP-815B
1. Generator Set:		
a. National Stock Number	6115-01-461-9335	6115-01-462-0290
b. Overall Length	79.7 in. (202.5 cm)	79.7 in. (202.5 cm)
c. Overall Width	35.7 in. (90.8 cm)	35.7 in. (90.8 cm)
d. Overall Height	55 in. (139.7 cm)	55 in. (139.7 cm)
e. Dry Weight (less Basic Issue Items List)	2732 lb. (1239.2 kg)	2732 lb. (1239.2 kg)
f. Wet Weight	2931 lb. (1329.5 kg)	2931 lb. (1329.5 kg)
2. Engine:		
a. Manufacturer	John Deere	John Deere
b. Model	4045TF151	4045TF151
c. Type	Four cylinder, four cycle, Turbocharged diesel	Four cylinder, four cycle, turbocharged diesel
d. Displacement	239 cu. in. (3.9 liters)	239 cu. in. (3.9 liters)
e. Altitude Degradation, 4000 ft. (1220 m) to 8000 ft. (2440 m)	3.5% per 1000 ft. (305 m)	3.5% per 1000 ft. (305 m)
f. Firing Order	1, 3, 4, 2	1, 3, 4, 2
g. Cold Weather Starting Aid System Use	40°F (4°C) or below	40°F (4°C) or below
h. Valve Tappet Clearance Adjustment: Hot or Cold (Intake) Hot or Cold (Exhaust)	0.014 in. (0.35 mm) 0.018 in. (0.45 mm)	0.014 in. (0.35 mm) 0.018 in. (0.45 mm)
3. Cooling System:		
a. Type	Pressurized radiator and Pump	Pressurized radiator and pump
b. Capacity	15.5 qts. (14.7 liters)	15.5 qts. (14.7 liters)
c. Normal Operating Temperature	170-200°F (77-93°C)	170-200°F (77-93°C)
d. Temperature Indicating System Voltage Rating	24 VDC	24 VDC
4. Lubricating System:		
a. Type	Full flow, circulating pressure	Full flow, circulating pressure
b. Oil Pump Type	Positive displacement gear	Positive displacement gear
c. Normal Operating Pressure	25-60 psi (172-414 kPa)	25-60 psi (172-414 kPa)
d. Oil Filter Type	Full flow, spin-on replacement element	Full flow, spin-on replacement element
e. Capacity	15 qts. (14.2 liters)	15 qts. (14.2 liters)
f. Pressure Indicating System Voltage Rating	24 VDC	24 VDC
5. Fuel System:		
a. Type of Fuel	DF-1, DF-2, DF-A, JP5, JP8	DF-1, DF-2, DF-A, JP5, JP8
b. Fuel Tank Capacity	23 gal. (87.05 liters)	23 gal. (87.05 liters)
c. Fuel Consumption Rate	2.60 gal. (9.8 liters) per Hour	2.75 gal. (10.4 liters) per hour
d. Auxiliary Fuel Pump: (1) Voltage Rating (2) Delivery Pressure	24 VDC 5.0-6.5 psi (34.5-65.5 kPa) (max.)	24 VDC 5.0-6.5 psi (34.5-65.5 kPa) (max.)
e. Injection Fuel Pump (1) Manufacturer (2) Model	Stanadyne DB4429-5281	Stanadyne DB4429-5281

TABLE 1-1. TABULATED DATA (continued)

	MEP-805B	MEP-815B
5. Fuel System (continued);		
f. Electric Actuator		
(1) Manufacturer	Governors of America	Governors of America
(2) Model	ADC100-24	ADC100-24
6. Engine Starting System:		
a. Batteries	Two 12 volt, connected in series	Two 12 volt, connected in series
b. Starter:		
(1) Manufacturer	Denso	Denso
(2) Model	RE 40595	RE 40595
(3) Voltage Rating	24 VDC	24 VDC
(4) Drive Type	Gear reduction	Gear reduction
c. Battery Charging Alternator:		
(1) Manufacturer	Bosch	Bosch
(2) Model	9 120 060 039	9 120 060 039
(3) Rating	42 amps at 24 VDC	42 amps at 24 VDC
(4) Protective Fuse	30 amps	30 amps
7. AC Generator:		
a. Manufacturer	Marathon Electric	Marathon Electric
b. Type	Rotating field, synchronous	Rotating field, synchronous
c. Load Capacity	30 kW	30 kW
d. Model	88-21007	88-21008
e. Current Ratings:		
(1) 120/208 volt connection	60 Hz: 104 amps 50 Hz: 86 amps	104 amps
(2) 240/416 volt connection	60 Hz: 52 amps 50 Hz: 43 amps	52 amps
f. Power Factor	0.8	0.8
g. Cooling	Fan cooled	Fan cooled
h. Drive Type	Direct coupling	Direct coupling
i. Duty Classification	Continuous	Continuous
8. Digital Control System:		
a. DCS Load Sharing Synchronizer:		
(1) Manufacturer	Governors of America	Governors of America
(2) Model	LSS100	LSS400
b. DCS Speed Control Unit:		
(1) Manufacturer	Governors of America	Governors of America
(2) Model	ESD5551	ESD5551
c. I/O Interface Module		
(1) Manufacturer	Governors of America	Governors of America
(2) Model	TCM100	TCM400
d. Backplane Module		
(1) Manufacturer	Governors of America	Governors of America
(2) Model	TCM102	TCM102
e. Automatic Voltage Regulator		
(1) Manufacturer	Governors of America	Governors of America
(2) Model	AVR100	AVR400

TABLE 1-2. PERFORMANCE CHARACTERISTICS

	MEP-805B	MEP-815B
1. Voltage:		
a. Voltage wave form deviation factor	5% (max.)	5% (max.)
Single voltage harmonics	2% (max.)	2% (max.)
b. Voltage unbalance	5% of rated voltage (max.)	5% of rated voltage (max.)
c. Phase balance voltage	1% of rated voltage (max.)	1% of rated voltage (max.)
d. Voltage modulation	1% (max.)	1% (max.)
e. Voltage regulation	1% (max.)	1% (max.)
f. Short-term stability (30 seconds)	1% of rated voltage	1% of rated voltage
g. Long-term stability (4 hours)	2% of rated voltage	2% of rated voltage
h. Voltage drift (60°F [16°C] in 8-hour period)	±1% (max.)	±1% (max.)
i. Dip and rise for rated load	15% of rated voltage (max.)	12% of rated voltage (max.)
Recovery time	0.5 seconds	0.5 seconds
j. Dip for low power factor load	30% of no-load voltage	25% of no-load voltage
Recovery time	(max.) 0.7 seconds 95% of no-load voltage	(max.) 0.7 seconds 95% of no-load voltage
k. Adjustment range VAC		
120/208V connection	50 Hz 190-213V	400 Hz 195-229V
240/416V connection	380-426V 60 Hz	395-458V
120/208V connection	197-240V	
240/416V connection	395-480V	
2. Frequency:		
a. Regulation	0.25% of rated frequency	0.25% of rated frequency
b. Short-term steady-state stability (30 seconds)	0.5% of rated frequency	0.5% of rated frequency
c. Long-term steady-state stability (4 hours)	1% of rated frequency	1% of rated frequency
d. Frequency drift (60°F [16°C] in 8 hour period)	0.5% (max.)	0.5% (max.)
e. Undershoot with application of load	4% of rated frequency (max.)	1.5% of rated frequency (max.)
Recovery time	2 seconds	1 second
f. Overshoot with application of load	4% of rated frequency (max.)	1.5% of rated frequency (max.)
Recovery time	2 seconds	1 second
g. Adjustment range	48-52 Hz, not below 45 Hz for 50 Hz operation	390-420 Hz, not below 370 Hz or above 430 Hz

Setpoints for MCII TQG with DCS

Generator Set Shutdowns				
Parameter	Requirement	Actual Trippoint	Warning	Notes
Oil Pressure	15 ± 3 psig	15 psig	25 psig	
Coolant Temperature	225 ± 5°F	239°F	229°F	Changed during FAT
Fuel Level	4 minutes run time at full load	7%	25%	
Overspeed	2200±40 rpm	2200 rpm	None	Corresponds to 73.3 Hz or 440 Hz
Overvoltage	153±3VAC (127%)	153VAC (120%)	132VAC (110%)	Must not actuate under 120 msec or longer than 1.25 seconds
Contactor Trips				
Short Circuit	50 millisec	50 millisec	None	Short circuit defined as 425±25% of rated current or greater
Overload	110% no trip, 130%-8±2 min, follows inverse time principle for increasing current	Time (min)	CIM Embedded Overload Trip Percent Current	>100%
		30.0	111%	
		8.0	130%	
		4.0	170%	
		1.0	230%	
		0.25	290%	
		0.05	350%	
Undervoltage	<48VAC Instantaneous Trip <99VAC 6±2 seconds	<48VAC Instantaneous Trip <99VAC 6 seconds	108VAC (90%)	
Reverse Power	20±3% rated load	20±3% rated load	None	
Other Setpoints				
Parameter	Requirement	Actual Trippoint	Warning	Notes
Auxiliary Fuel Pump	As needed	ON at 55% falling OFF at 70% rising	None	




FIGURE 1-16. FUEL SYSTEM DIAGRAM PLATE

NOTES

[Faint, illegible text, possibly bleed-through from the reverse side of the page]

TABLE 1-1. TABLE OF SPECIFICATIONS

Model.....	John Deere TO4045TF150
Type	EPA compliant four cylinder, four cycle, turbocharged diesel
Bore	4.19 in. (106 mm)
Stroke.....	5.00 (127.0 mm)
Displacement	276 cu in. (4.5 liters)
Compression Ratio	17.0:1
Firing Order	1-3-4-2
Width	23.5 in. (598 mm)
Height.....	38.6 in. (980 mm)
Length.....	33.9 in. (861 mm)
Weight	872 lbs (396 kg)
Injection Pump/Governor	Stanadyne Model DB4
Injection Starting Pressure	
New	3,660 psi (25,200 kPa) min
Used.....	3,330 psi (22,950 kPa) min
Cylinder Compression Pressure	350 psi (2400 kPa) min
Lubrication System Capacity.....	14.0 qts (13 liters)
Coolant System capacity (engine only).....	15.5 qts. (14.7 liters)
Alternator.....	Bosch 28 volt DC - 45 amp
Starter	Nippon-Denso 24 volt DC - 4.5 kw

1.11 DATA PLATES.

Refer to Table 1-2 for the engine option codes. The engine option codes data plate is affixed to the top of the rocker arm cover (4, Figure 1-1). These codes indicate which of the engine options were installed on your engine at the factory. These codes are important when parts and service are required. The engine option code includes an engine base code (1, Figure 1-2) which identifies the basic engine installed. The engine option code consists of a four-digit number. The first two digits of each code identify a specific group, such as alternators. The last two digits of each code identify one specific option provided on your engine, such as 12-volt, 55-amp alternator. If an engine is ordered without a particular component, the last two digits of that functional group option code will be 99, 00, or XX.




FIGURE 1-2. OPTION CODE LABEL

TABLE 1-2. ENGINE OPTIONS CODES - 4 CYLINDER, 4.5 LITER

ENGINE BASE CODE: 2116F

OPTION CODES	DESCRIPTION	REMARKS
1103	Rocker Arm Cover	
1214	Oil Filler Neck	
1302	Crankshaft Pulley	
1404	Flywheel Housing	
1503	Flywheel	
1677	Fuel Injection Pump	
1701	Air Inlet	
1936	Oil Pan	
2002	Water Pump	
2112	Thermostat Cover	
2201	Thermostat	
2301	Fan Drive	
2485	Fan Belt	
2599	Fan	Not installed on engine at factory.
2699	Engine Coolant Heater	Not installed on engine at factory.
2803	Exhaust Manifold	
2999	Ventilator System	Not installed on engine at factory.
3044	Starting Motor	
3110	Alternator	
3516	Fuel Filter	
3601	Front Plate	
3702	Fuel Transfer Pump	
3999	Thermostat Housing	Not installed on engine at factory.
4020	Oil Dipstick	
4199	Belt Driven Front Auxiliary Drive	Not installed on engine at factory.
4399	Starting Aid	Not installed on engine at factory.
4401	Timing Gear Cover with Gears	
4502	Balancer Shaft	
4601	Cylinder Block With Liners and Camshaft	
4701	Crankshaft and Bearings	

TABLE 1-2. ENGINE OPTIONS CODES - 4 CYLINDER, 4.5 LITER - CONT.

ENGINE BASE CODE: 2116F		
OPTION CODES	DESCRIPTION	REMARKS
4803	Connecting Rods and Pistons	
4901	Valve Actuating Mechanisms	
5002	Oil Pump	
5102	Cylinder Head With Valves	
5501	Shipping Stand	
5602	Paint Option	
5707	Water Pump Inlet	
5904	Oil Cooler	
6099	Add-on Auxiliary Drive Pulley	Not installed on engine at factory.
6212	Alternator Mounting	
6499	Exhaust Elbow	Not installed on engine at factory.
6524	Turbocharger	
6699	Temperature Switch	Not installed on engine at factory.
6799	Electronic Tachometer Sensor	Not installed on engine at factory.
6901	Engine Serial Number Plate	
7499	Air Conditioner Compressor Mounting	Not installed on engine at factory.
7699	Oil Pressure Switch	Not installed on engine at factory.
8604	Fan Pulley	
8799	Automatic Belt Tensioner	Not installed on engine at factory.
8803	Oil Filter	

Section I. PRINCIPLES OF OPERATION

2.1. INTRODUCTION.

This section contains functional descriptions of the engine systems and how they are connected to the end item.

2.2. COOLING SYSTEM.

The cooling system consists of a radiator, hoses, a thermostat, a belt driven fan, a water pump, and cooling jackets within the engine. The water pump forces coolant through passages (coolant jackets) in the engine block and oil cooler where coolant absorbs heat from the engine. When the coolant temperature is below operating temperature, the thermostat is closed and coolant is bypassed to the water pump inlet. As coolant temperature increases to 180E F (82E C), the thermostat fully opens, shutting off all bypass flow and providing full flow through the radiator. Air forced through the fins of the radiator by the fan cools the coolant pumped through the radiator. Items are added to the engine to monitor coolant temperature and to warn if temperature exceeds a predetermined value.

2.3. LUBRICATION SYSTEM.


The pressure lubrication system consists of a positive displacement gear-driven pump, filter strainer in the suction pipe, full flow oil filter, oil cooler, oil pressure regulating valve, and oil bypass valve. Additionally, the oil cooler and oil filter have their own bypass valve. The pump draws lubrication oil from the crankcase through a strainer and a suction line. The oil is then pumped through an oil line to the oil cooler, oil filter, and through the main oil gallery of the cylinder block. From the oil gallery, oil is forwarded under pressure to the main bearings and spray jets to cool the pistons. Drilled cross passages in the crankshaft distribute oil from the main bearings to connecting rod bearings and camshaft bearings. A drilled passage from the rear camshaft bearing through the cylinder block and cylinder head supplies lubricating oil to the rocker arm shaft. A turbocharger oil supply line provides lubricating oil to the shaft of the turbocharger. Items are added to monitor oil pressure and to warn the operator or stop the engine if pressure drops to a dangerously low value.

2.4. FUEL SYSTEM.

The fuel system consists of an external fuel tank, fuel supply pump, fuel filter, fuel injection pump, fuel injectors, and piping. The fuel supply pump draws fuel from the tank and pressurizes it. This pressure permits the fuel to flow through the fuel filter and charge the transfer pump of the fuel injection pump. With the fuel injection pump charged with fuel by the fuel supply pump, the fuel injection pump plungers pressurize the fuel to approximately 3,660 psi (25,200 kPa). Delivery (pressure) lines are used to route this high pressure fuel to the fuel injection nozzles. Fuel enters the injection nozzle at a pressure which easily overcomes the pressure required to open the nozzle valve. When the nozzle valve opens, fuel is forced out through the orifices in the nozzle tip and atomizes as it enters the combustion chamber. The fuel that is not used by the injectors and injection pump is returned to the fuel tank via an excess fuel return line.

2.5. ELECTRICAL SYSTEM.

The electrical system consists of external mounted batteries, starter, battery charging alternator, and related relays and switches for control of the system. Battery power supplied to the starter during the start cycle energizes the starter which engages the ring gear of the flywheel causing the engine to turn over. When engine start is complete, the starter is deenergized and disengages from the flywheel. The battery charging alternator is belt driven. It is a 45 ampere, 28 VDC alternator that when operating supplies voltage to recharge the batteries and maintain them at a full state of charge.



ENGINE COMPONENTS

- 1. Lifting Lug
- 2. Turbocharger
- 3. Intake Manifold
- 4. Rocker Arm Cover
- 5. Coolant Outlet
- 6. Battery Charging Alternator
- 7. Fan Pulley
- 8. Oil Fill Tube
- 9. Fan Drive Belt
- 10. Oil Filter and Cooler
- 11. Crankshaft Pulley
- 12. Oil Pan
- 13. Dipstick
- 14. Fuel Supply Pump
- 15. Starter
- 16. Fuel Filter
- 17. Exhaust Manifold
- 18. Flywheel Housing
- 19. Fuel Injection Pump
- 20. Coolant Intake




FIGURE I-1. ENGINE COMPONENTS

Section II. EQUIPMENT DESCRIPTION AND DATA

1.8. GENERAL.

The diesel engine (Figure 1-1) is four cylinder, four cycle, fuel injected, turbocharged, and liquid cooled. The firing order is 1-3-4-2. The number one cylinder is toward the fan end of the engine. The serial number is found on top of valve cover. Rotation of engine is counterclockwise as viewed from rear of engine facing forward.

NOTE

All locations referenced herein are given from rear of engine facing forward.

1.9. DETAILED DESCRIPTION.

- a. Turbocharger. A turbocharger, operated by exhaust gases, compresses intake air and routes it to the combustion chamber.
- b. Camshaft. The camshaft is driven by an intermediate gear in the timing gear train which meshes with the crankshaft gear. Camshaft rotates in honed machined bores in cylinder block; no bushings are used. The camshaft lobes determine the time and rate of opening of each valve and actuates the fuel supply pump.
- c. Intake and Exhaust Valves. Intake and exhaust valves are operated by cam followers, push rods, and rocker arm assembly. Valve seat inserts in cylinder head are used for intake and exhaust valves.
- d. Crankshaft. The crankshaft is a one-piece, heat treated, steel forging which operates in replaceable two-piece main bearings. The rear thrust bearing has a flange on each side to support crankshaft thrust and to limit end play.
- e. Cylinder Liners and Pistons. Cylinder liners are "wet" (surrounded by coolant) and are individually replaceable. O-rings are used to seal the connection between cylinder block and liners. Pistons are made of cast high-grade aluminum alloy with internal ribbing. The skirt is cam ground to allow for expansion when heated during operation. The piston crown has a cut-out swivel cup with a truncated cone in the center. Two compression rings and one oil control ring are used. The top compression ring is a keystone type ring. All piston rings are located above the piston pin. The hardened piston pins are fully-floating and held in position by means of retainer rings. Spray jets (piston cooling orifices) in cylinder block direct pressurized oil to lubricate piston pins and cool pistons. Connecting rods are forged steel and have replaceable bushing and bearing inserts.
- f. Cooling System. The cooling system consists of a radiator, water pump, cooling fan, thermostat, and connecting hoses. The fan and water pump are both belt driven from the crankshaft pulley. The thermostats control engine temperature and are installed in top of engine. The function of the cooling system is to maintain a specific operating temperature of 180 to 220°F (82 to 104°C) for the engine.
- g. Lubrication System. The lubrication system consists of oil pan (sump), a gear type pump, full flow spin-on oil filter with built-in bypass valve, oil cooler with built-in bypass valve, pressure regulating valve, bypass valve, and the internal passages.
- h. Fuel System. The function of the fuel system is to inject a metered quantity of clean atomized fuel into the engine cylinders at a precise time near the end of the compression stroke of each piston. The fuel system consists of the fuel tank, fuel filter/water separator, fuel supply pump, fuel injection pump, and the fuel injectors. The fuel tank is not mounted on the engine. The fuel supply pump is mounted to the block and is driven by the camshaft. The fuel injection pump is mounted on the front plate and is driven by an intermediate gear in the timing gear train meshing with crankshaft gear.
- i. Electrical System. The electrical system is 28VDC operation and consists of a battery charging alternator, starter, externally mounted batteries, and other items as required. The battery charging alternator is mounted on front of engine and is belt driven. When engine is operating, the battery charging alternator supplies 28VDC to recharge the batteries and maintain them at a full state of charge. The starter is mounted on the flywheel housing, and when energized, engages the ring gear of the flywheel to rotate the engine.

SECTION III. PRINCIPLES OF OPERATION

1.15 INTRODUCTION.

This section contains functional descriptions of the generator set. How the controls and indicators interact with the system is explained as well as the location and description of major components.

1.16 PRINCIPLES OF OPERATION.

1.16.1 Digital Control System (DCS).

1.16.1.1 The DCS is a closed-loop system providing the operator with real-time system status information and control. It includes automatic shutdown features if critical components fail to protect the generator set from damage and to prevent damaging output power and voltage levels. It includes a digital computer using software to process inputs from the generator set and from the operator. The DCS accepts operator commands to adjust various generator set parameters such as frequency and voltage. The DCS also facilitates operating two or more generator sets in parallel. The DCS can be operated at the generator set or from a remote location using an IBM-compatible personal computer (PC)

1.16.1.2 In the event that the computer operating software is lost or operating incorrectly, the software must be restored. Procedures are provided for TQG remote software restoration in Paragraph 2.13.2.

1.16.1.3 Eight major components or modules are included in the DCS: The DCS speed control unit, automatic voltage regulator, load sharing synchronizer, I/O interface module, backplane module, electric actuator, computer interface module (CIM), and keypad assembly. The DCS provides multiple, integrated functions as the controller of the fault, governor, and voltage regulation systems, as described below.

1.16.1.4 The CIM is the primary operator interface with the DCS. It is a self-contained IBM compatible computer with an AMD 486 processor running the Windows CE operating system. An internally lit Liquid Crystal Display (LCD) screen provides the operator with status displays and control capability. A cursor symbol on the display is controlled by the keypad assembly, which is a set of four arrow keys and a SELECT key to enter commands. The load sharing synchronizer is used when paralleling the generator set to a main bus or to another generator set. This module provides signals to the DCS speed control unit to adjust engine speed settings to maintain a match between the outputs of the two generator sets. The I/O interface module controls and interfaces with all the other components in the DCS. For example, it receives inputs from engine sensors and converts them for use by the CIM. Most of the DCS signals, including control panel inputs, are routed through this module. The status of the I/O interface module is indicated by a green HEARTBEAT light emitting diode (LED) which blinks at a rate of approximately two times per second to indicate the module is operational.

The backplane module is an installation point for three DCS modules and for the main electrical connectors from the AC generator. It connects the front panel switches and these DCs modules with the I/O interface module. This module simplifies the wiring inside the DCS control box by placing many interconnections onto one circuit board assembly. This module also includes diagnostic indicators for the DCS. The other DCS modules are discussed in paragraphs below.

1.16.2 Fault System.

1.16.2.1 The Fault System (Figure 1-19) protects the generator set and any connected load against the potential faults described below and provides an indication of any incurred fault. The following summary of the Fault System will assist in understanding the operation of other generator set systems. Additional details relating to specific protection devices are provided in the descriptions of the respective systems.




FIGURE 1-19. FAULT SYSTEM FLOW DIAGRAM

- 1.16.2.2 The Fault System consists of the CIM, I/O interface module, fuel level sender, oil pressure sender, coolant temperature sender, and BATTLE SHORT switch.
- 1.16.2.3 Inappropriate signals received from the senders by the I/O interface module will cause the CIM to display the fault, and a message describing the condition causing the fault, on the CIM display screen. Depending on the nature of the fault, the generator set will shut down or the operator will be warned that action must be taken to avoid shutdown.
- 1.16.2.4 Activation of the fault system will cause two events to occur. The AC interrupter relay will open and CONTACTOR POSITION status indicator on CIM display screen will indicate OPEN.
- 1.16.2.5 Although it is possible for more than one fault to occur at one time during operation, and for more than one fault to be displayed on the CIM display screen at a time, only the first fault to occur will cause a message to appear in the MESSAGES display area of the CIM display screen. Once the condition addressed in that message has been corrected by the operator, the operator will activate the FAULT RESET switch, and the next message will be displayed.
- 1.16.2.6 After the generator set engine has been started, the BATTLE SHORT switch may be used to override all potential faults except engine overspeed and short circuit.
- 1.16.3 Governor Control System.
- 1.16.3.1 The governor control system (Figure 1-20) includes the DCS speed control unit, electric actuator, DCS load sharing synchronizer, magnetic pickup, fuel injection pump, and FREQUENCY SELECT switch.
- 1.16.3.2 The electric actuator controls the output of the fuel injection pump in response to the electrical input from the DCS speed control unit. The DCS provides a signal representing the desired engine speed/generator frequency to the DCS speed control unit. A signal representative of the actual engine speed/generator frequency is sent to the DCS speed control unit by the magnetic pickup. Any change in engine speed from that selected by the operator, as sensed by the magnetic pickup, causes the DCS speed control unit to increase or decrease fuel injection pump output to maintain the desired speed. Generator set frequency and power output are indicated on the CIM display screen. The FREQUENCY SELECT switch is used to set the generator for 50 hertz or 60 hertz operating frequencies (MEP-805B only).
- 1.16.3.3 Twenty-four VDC power is supplied to the DCS speed control unit through the governor control power relay. The governor control power relay is controlled by the fault system. The DCS speed control units of two generator sets operating in parallel are interconnected by the paralleling cable.
- 1.16.4 Voltage Regulation System.
- The Voltage Regulation System (Figure 1-21) consists of the automatic voltage regulator and power potential transformer. The automatic voltage regulator senses and controls generator output voltage which is operator adjustable within the design limits by use of the VOLTAGE ADJUST switch. The power potential transformer provides operating power to the automatic voltage regulator module. Generator output voltage is indicated on the CIM display screen.
- 1.16.5 Fuel System.
- 1.16.5.1 The Fuel System (Figure 1-22) includes a primary subsystem and an auxiliary subsystem.
- 1.16.5.2 The primary subsystem consists of fuel lines, fittings, fuel tank, fuel level sender, transfer pump, fuel filter/water separator, injection pump, DCS speed control unit, and injectors. The injection pump includes a 24 VDC fuel shutoff valve.




FIGURE 1-20. GOVERNOR CONTROL SYSTEM FLOW DIAGRAM




FIGURE 1-21. VOLTAGE REGULATION SYSTEM FLOW DIAGRAM




FIGURE 1-22. FUEL SYSTEM FLOW DIAGRAM

- 1.16.5.3 The injection pump output is controlled by the DCS speed control unit and electric actuator. The DCS speed control unit is energized whenever the ENGINE CONTROL switch is in the START position or either of the two RUN positions. With the engine cranking or running, fuel is drawn from the fuel tank by the transfer pump. After reaching the transfer pump, fuel passes through a fuel filter/water separator where water and small impurities are removed. The fuel then goes to the injection pump. With the governor system energized, the fuel is metered, pressurized and pushed through the injectors by the injection pump. Fuel is sprayed by the injectors into the diesel engine combustion chambers where it is mixed with air and ignited. Fuel that is not used by the injectors is returned to the fuel tank by an excess fuel return line. Power is removed from the DCS speed control unit, and the fuel is shut off whenever the ENGINE CONTROL switch is set to the OFF position. The DCS speed control unit is also de-energized by the fault system, paragraph 1.14.2. The CIM display screen FUEL LEVEL indicator displays the fuel level of the fuel tank from E (empty) to F (full) expressed as percent remaining.
- 1.16.5.4 The auxiliary subsystem consists of an auxiliary fuel supply, fuel lines, fittings, and an auxiliary fuel pump.
- 1.16.5.5 When the ENGINE CONTROL switch is set on PRIME & RUN AUX FUEL, it actuates the auxiliary fuel pump and transfers fuel from the auxiliary fuel supply to the fuel tank. The CIM shuts off the auxiliary fuel pump when the fuel tank is full and reactivates the pump as the level drops.
- 1.16.5.6 The 24 VDC control circuits provide control and power for indicators, fault system, DCS, and auxiliary fuel pump.
- 1.16.6 Mechanical System.
- 1.16.6.1 The mechanical system provides protection from the elements, structural integrity, transportability, noise suppression, and the cooling system for the generator set. The generator set cooling system is described separately below.
- 1.16.6.2 The mechanical system consists of the housing, insulation, air baffles, and skid base.
- 1.16.6.3 The generator set housing is insulated to provide "tactical quiet" noise suppression which makes detection of the generator set by its audio signature more difficult under battle conditions. Air baffles allow for airflow to cool the generator set with as little impact as possible to the generator set's noise output.
- 1.16.6.4 The skid base provides a stable base for the generator set during operation and transport, and allows the generator set to be moved by forklift or mounted on a trailer.
- 1.16.7 Generator Set Cooling System.
- 1.16.7.1 The Generator Set Cooling System (Figure 1-23) includes air intake and exhaust grilles, baffles, and ducting within the generator set housing and the engine driven radiator cooling fan. The air intake grilles are located in panels on both sides of the generator set housing. The air exhaust grille is located in the housing top panel.
- 1.16.7.2 Air is drawn in through the air intake grilles and forced through the engine coolant radiator and out of the generator set through the exhaust grille by the radiator cooling fan. Most of the cooling air flows externally past the generator assembly and engine. Some cooling air is circulated internally through the generator assembly by a generator fan which is an integral part of the AC generator assembly. Baffles, ducting, and sound absorbing material are used to control the air flow through the generator set and to reduce sound transmission through the grilles.




FIGURE 1-23. GENERATOR SET COOLING SYSTEM FLOW DIAGRAM

1.16.8 Engine Cooling System.

1.16.8.1 The Engine Cooling System (Figure 1-24) consists of a radiator, hoses, thermostat, coolant temperature sender, CIM display screen COOLANT TEMP indicator, water pump, oil cooler, cooling fan, and cooling jackets (part of engine).

1.16.8.2 The water pump forces coolant through passages (cooling jackets) in the engine block and cylinder head where the coolant absorbs heat from the engine. When the engine reaches normal operating temperature, the thermostat opens and the heated coolant flows through the upper radiator hose assembly into the radiator. The cooling fan circulates air through the radiator where the coolant temperature is reduced.

1.16.8.3 The DCS, in conjunction with the fault system, provides automatic shutdown in the event coolant temperature exceeds $230 \pm 5^{\circ}\text{F}$ ($110 \pm 3^{\circ}\text{C}$). The CIM display screen COOLANT TEMP indicator indicates the engine coolant temperature from 100°F to 250°F (38°C to 121°C).

1.16.8.4 The water pump also circulates coolant through the engine oil cooler to cool the engine oil.

1.16.9 Lubrication System.

1.16.9.1 The Engine Lubrication System (Figure 1-25) consists of an oil pan, dipstick, pump, oil cooler, oil sample valve, oil pressure sender, CIM display screen OIL PRESSURE indicator, oil drain valve, and filter.

1.16.9.2 The oil pan is a reservoir for engine lubricating oil. The dipstick indicates oil level in the pan. The oil level can be checked during engine operation. One side of the dipstick is used for checking oil level while the engine is running and the other side is used while the engine is shut down. The pump draws oil from the oil pan through a screen which removes large impurities. The oil then passes through tubes in the oil cooler. Engine coolant from the engine cooling system is circulated around the tubes to cool the oil. From the cooler, oil passes through a spin-on type filter where small impurities are removed. From the filter, oil is distributed to the engine and turbocharger moving parts and then returns to the oil pan. The oil pressure sender located in the engine block senses oil pressure. Oil pressure is displayed on the CIM display screen OIL PRESSURE indicator. An Army Oil Analysis Program (AOAP) sample valve located in the block allows oil samples to be taken while the engine is operating. The DCS automatically shuts off the engine if oil pressure drops below 15 ± 3 psi (103.4 ± 20.7 kPa).

1.16.10 Engine Air Intake and Exhaust System.

1.16.10.1 The Engine Air Intake and Exhaust System (Figure 1-26) consists of an air cleaner assembly, intake manifold, ether supply tank, ether solenoid valve, ETHER START switch, exhaust manifold, turbocharger, muffler, and crankcase breather filter. The air cleaner assembly includes a dust collector, filter element, restriction indicator, and dust evacuator valve.

1.16.10.2 Air is drawn into the dust collector and passes through the filter element. Airborne dirt is removed and trapped in the dust collector and filter element. Some dust can be removed from the dust collector by pinching the evacuator valve. The restriction indicator indicates when the filter should be serviced. Filtered air is drawn out of the filter through air intake tubes into the turbocharger where it is compressed and forced into the engine.




FIGURE 1-24. ENGINE COOLING SYSTEM FLOW DIAGRAM




FIGURE 1-25. LUBRICATION SYSTEM FLOW DIAGRAM




FIGURE 1-26. ENGINE AIR INTAKE AND EXHAUST SYSTEM FLOW DIAGRAM

- 1.16.10.3 Engine exhaust gases are expelled into the exhaust manifold and ported to the turbine of the turbocharger. The turbine drives the turbocharger compressor which compresses the intake air. Exhaust gases discharged by the turbocharger are channeled into the muffler that deadens the sound of the exhaust gases. Gases pass from the muffler through the muffler outlet and are vented upward from the generator set housing. A cover, which is held open by the pressure of the exhaust gases during operation, closes over the exhaust port to prevent rain, water, or other foreign matter from entering the exhaust port when the set is not in use. The cover is easily removed for connection of an exhaust pipe for indoor operation.
- 1.16.10.4 Combustion gases, which enter the crankcase, are filtered through the crankcase breather filter to remove oil droplets and are then recycled through the intake manifold.
- 1.16.10.5 An ether supply system is provided to improve engine starting when outside ambient air temperature is below 40°F (4°C). The ether system includes an ether supply tank, ether solenoid valve, ETHER switch, and piping from the solenoid valve to the intake manifold. The ether system is activated by turning the ENGINE CONTROL switch to START and momentarily holding the ETHER switch in the ON position while continuing to crank engine.
- 1.16.10.6 Air in the engine crankcase is drawn out the right side of the engine through a rubber hose and into the crankcase breather filter assembly. There the air swirls around, leaving oil particles in the removable filter, and leaves through a second rubber hose. The air then passes through this output hose into the engine air cleaner assembly output hose. That is, the filtered air from the crankcase enters the engine intake air flow downstream of the intake air filter. Engine intake air flow is then compressed with the turbocharger, enabling filtered crankcase air to be recycled into the engine intake air and used in the combustion process of the engine.
- 1.16.11 Output Supply System.
- 1.16.11.1 The Output Supply System (Figure 1-27) consists of the AC generator, ground fault circuit interrupter, CONVENIENCE RECEPTACLE, current transformer, voltage reconnection terminal board, AC circuit interrupter, load output terminals, AC CIRCUIT INTERRUPT switch, load sharing synchronizer, automatic voltage regulator, CIM display screen FREQ gage, VOLTAGE gage, and POWER gage.
- 1.16.11.2 Power created by the generator is supplied through the current transformer, voltage reconnection terminal board, and AC circuit interrupter to the load output terminals. The voltage reconnection terminal board allows configuration of the generator set for 120/208 volt connections or 240/416 volt connections. The AC CIRCUIT INTERRUPT switch closes and opens the AC circuit interrupter. This enables or interrupts power flow between the voltage reconnection terminal board and load output terminals. The voltage regulation system (paragraph 1.14.4) senses generator output voltage and provides a control signal to the generator exciter to maintain the desired generator output voltage. Generator output frequency is controlled by the governor control system (paragraph 1.14.3) and is read on the CIM display screen FREQ gage (Hz). The current transformer provides a reduced current signal to the DCS and CIM display screen GEN CURRENT indicators (amps AC). The CIM display POWER gage (kW) provides an indication of the power being used by the load. The GEN AMMETER indicates rated current in amps required by the load. The AC circuit interrupter will open and disconnect the load whenever any of the following faults occur: reverse power, undervoltage, overload, overspeed, low oil pressure, high water temperature, or short circuit.
- 1.16.11.3 The AC generator also provides 120 VAC power to the CONVENIENCE RECEPTACLE through the GROUND FAULT CIRCUIT INTERRUPTER.




FIGURE 1-27. OUTPUT SUPPLY SYSTEM FLOW DIAGRAM

1.16.12 Generator Assembly.

1.16.12.1 **General.** Revolving field type generators have a DC field revolving within a stationary AC winding called the stator. See brushless generator schematic, Figure 1-28. AC power is distributed from the generator through leads connected to the stator windings. There are no sliding contacts between the AC winding and the load, therefore, great amounts of power may be drawn from this generator.

To energize the field, DC excitation must be applied to the generator field coils. The excitation current is supplied from a brushless exciter mounted on the generator shaft.

The brushless exciter is actually an AC generator with its output rectified through a full wave bridge circuit. This type of brushless exciter will provide the necessary excitation current. The generator set field flash circuit, activated during each engine start, applies voltage to the exciter stator to begin the voltage build-up process to energize the generator field.

The generator output voltage is controlled by controlling the alternating field current. This is accomplished by regulating the exciter field coil voltage. The exciter field coil voltage is regulated with a solid state type automatic voltage regulator.

1.16.12.2 **Damper Bars.** Damper bars are inserted through the field laminations and welded at the end to a solid copper plate. The damper windings provide stable parallel operation, reduce damping current losses, and limit the increase of third harmonic voltage with increase in load.

1.16.12.3 **Brushless Exciter.** The brushless exciter consists of an armature with a three-phase AC winding and rotating rectifier assembly within a stationary field.

The stationary exciter field assembly is mounted in the main generator frame. The exciter armature is press fit and keyed onto the shaft assembly. The rotating rectifier assembly slides over the bearing end of the generator rotor shaft and is secured with bolts and washers to an adapter hub which is shrunk on the generator shaft.

1.16.12.4 **Rotating Rectifier Bridge.** The rotating rectifier bridge consists of rectifying diodes mounted on a brass heat sink which is in turn mounted on an insulating ring. The entire assembly bolts to the adapter on the generator shaft. Therefore, the rotating rectifier assembly will rotate with the exciter armature eliminating the need for any sliding contacts between the exciter output and the alternator field.

1.16.12.5 **Exciter Field.** The exciter field on the high frequency exciter consists of laminated segments of high carbon steel which are fitted together to make up the field poles. The field coils are placed into the slots of the field poles.

1.16.12.6 **Exciter Field Coil Voltage Source.** Field coil DC voltage is obtained by rectifying the voltage from a phase to neutral line of the generator output, or other appropriate terminal, to provide the needed voltage reference.

The rectifier bridge is an integral part of the static regulator. The static regulator senses a change in the generator output and automatically regulates current flow in the exciter field coil circuit to increase or decrease the exciter field strength. An external adjust rheostat sized to be compatible with the regulator is used to provide adjustment to the regulator sensing circuit.

1.16.12.7 **Balance.** The rotor assembly is precision balanced to a high degree of static and dynamic balance. Balance is achieved with the balance lugs on the field pole tips. The balance will remain dynamically stable at speed in excess of the design frequencies.




FIGURE 1-28. BRUSHLESS GENERATOR SCHEMATIC

- 1.16.12.8 Bearing. The generator rotor assembly is suspended on shielded, factory lubricated ball bearings. They are greased for life and do not require lubrication.
- 1.16.12.9 Stator Assembly. The stator assembly consists of laminations of steel mounted in a rolled steel frame. Random wound stator coils are fitted into the insulated slots.

1.16.13 Generator Set Controls.

1.16.13.1 Engine Starting System.

- 1.16.13.1.1 Engine starting is accomplished primarily with two 12 volt batteries, connected in series to provide 24 VDC power, and a starter (Figure 1-29). The starter includes a cranking motor and a solenoid. To permit engine starting, the DC CONTROL POWER circuit breaker must be pushed in, the DEAD CRANK switch must be in the NORMAL position, and the BATTLE SHORT switch must be in the OFF position. In addition, any ENGINE SHUTDOWN fault previously registered on the CIM display screen must have been corrected by activating the FAULT RESET switch.

When the ENGINE CONTROL switch is then placed in the START position, the starting circuits supply 24 VDC power to the starter. As the engine accelerates to approximately 900 RPM, the DCS speed control unit disconnects power from the starter.

- 1.16.13.1.2 When the ENGINE CONTROL switch is first moved to the START position, the control modules are energized. The Engine Starting System includes three control circuits. One starting control circuit energizes the K2 relay through closed switch contacts of the crank disconnect relay. The second starting control circuit signals the I/O interface module. With the K2 relay energized, power passes from the batteries through closed contacts of the K2 relay to energize the starter solenoid. With the starter solenoid energized, power passes from the starter solenoid to the cranking motor. The cranking motor then cranks the engine. Engine speed is sensed by the magnetic pickup which sends a signal to the DCS speed control unit. As the engine accelerates to approximately 900 RPM, the signal from the magnetic pickup causes the crank disconnect switch to open the crank disconnect relay. The open contacts break the circuit to the cranking relay and stop engine cranking. The third control circuit causes the field flash relay to be energized. When the ENGINE CONTROL switch is moved to one of the two RUN positions, all starting control circuits are de-energized. The other generator set control and instrument circuits remain energized.
- 1.16.13.1.3 The engine may be cranked without starting by use of the DEAD CRANK switch. With the DEAD CRANK switch in the CRANK position, the K2 relay coil is energized to initiate engine cranking without energizing any other starting or control functions.
- 1.16.13.1.4 The generator set can be started without batteries by connecting an external 24 VDC power source to the NATO/SLAVE RECEPTACLE. The generator set can also supply power to another set through the NATO/SLAVE RECEPTACLE.
- 1.16.13.1.5 The batteries are charged by the battery charging alternator which is belt driven by the engine. The CIM display screen BATTERY CHARGE ammeter indicates the charge/discharge rate of the batteries, from -60 amps to +60 amps. A sensor provides a DC voltage signal, which is directly proportional to the actual battery current flow, to the BATTERY CHARGE ammeter. Normal operating indication on the BATTERY CHARGE ammeter depends on the state of the charge in the batteries. A low charge, which may exist immediately after engine starting, will cause a high reading (indication toward CHARGE area). When the charge in the batteries has been restored, the indicator moves near zero. The battery charging system is protected from reverse polarity in the battery connections by a diode.




FIGURE 1-29. ENGINE STARTING SYSTEM FLOW DIAGRAM

- 1.16.13.2 **Field Flash.** This circuit provides current to the exciter field windings which sets up an electromagnetic field. The field current is necessary for the set to generate sufficient voltage for the automatic voltage regulator to begin controlling the output voltage of the generator set. The field flash circuit is maintained until the ENGINE CONTROL switch is released from the START position.
- 1.16.13.3 **Operation.** Placing the ENGINE CONTROL switch in the PRIME & RUN AUX FUEL positions keeps the DCS speed control unit energized, and fuel will be supplied to the fuel injection pump as long as no fault condition exists. During operation, the operator should periodically check the CIM display screen to ensure readings are in normal operating ranges. The VOLTAGE ADJUST and FREQUENCY ADJUST switches are adjusted as required to maintain desired frequency and voltage output.
- 1.16.13.4 **Applying the Load.** The load is applied by placing the AC CIRCUIT INTERRUPT switch in the CLOSED position. This is a momentary contact switch that returns to the neutral, or center, position. The AC circuit interrupter is energized by this momentary contact and a holding circuit keeps it closed, bringing the load on line.
- 1.16.13.5 **Shutdown.**
- 1.16.13.5.1 The AC circuit interrupter is disengaged by placing the AC CIRCUIT INTERRUPT switch in the OPEN position. This is a momentary contact switch which will break the AC circuit interrupter holding circuit and then return to the neutral, or center, position, disconnecting the load from the line.
- 1.16.13.5.2 The generator set should remain running for five minutes after disconnecting the load. During this five minute interval, oil circulates through the turbocharger, cooling it enough to be shut down.
- 1.16.13.5.3 When the ENGINE CONTROL switch is placed in the OFF position, all power is removed from the governor control circuit and the engine will stop.
- 1.16.13.5.4 The EMERGENCY STOP switch will remove power from the governor control circuit by de-energizing circuitry in the DCS. This will cause the engine to shut down. The EMERGENCY STOP switch will not be used as an alternative for routine shutdown procedures. When the generator set is stopped using the EMERGENCY STOP switch, some circuits remain energized causing a drain on the batteries until the ENGINE CONTROL switch is placed in the OFF position.
- 1.16.13.6 **Paralleling.**
- 1.16.13.6.1 The generator set is capable of being operated in parallel with one other set of the same model number. This capability is provided by the PARALLELING RECEPTACLE, paralleling cable, and the load sharing synchronizer.
- 1.16.13.6.2 The paralleling cable is used to interconnect the governor and automatic voltage regulator paralleling circuits of the two sets. Voltage and frequency of the two generator sets are synchronized by the DCS load sharing synchronizer. The permissive paralleling relay monitors the voltage phase relationship and prevents the AC circuit interrupter from closing when the units are not properly synchronized.

NOTES




FIGURE 2-1. DCS CONTROLS AND INDICATORS

TABLE 2-1. DCS CONTROLS AND INDICATORS


KEY	CONTROL OR INDICATOR	FUNCTION
1	ELAPSED TIME Meter	Indicates total engine operating hours.
2	Panel Lights	Illuminate DCS control panel.
3	EMERGENCY STOP Switch	Shuts down generator set when activated. Removes electrical power to governor controller and stops engine from operating.
4	PANEL LIGHTS Switch	Activates and deactivates panel lights.
5	NETWORK FAILURE Indicator	When illuminated indicates a failure between Computer Interface Module and Input/Output Module. Generator set will not continue to operate, and capability to monitor its operation and to make adjustments will be degraded or lost.
6	BATTLE SHORT Switch	Bypasses protective devices on generator set. Set will continue to operate until overvoltage occurs or fuel is exhausted.
7	ETHER START Switch	When held in ON position momentarily during engine cranking, activates ether cold weather starting system for starting engine at temperatures below 40°F (4°C).
8	ENGINE CONTROL Switch	Four position switch: OFF – de-energizes all circuits except panel lights and power to CIM. PRIME & RUN AUX FUEL – energizes generator set run circuits with auxiliary fuel pump operating. PRIME & RUN – energizes generator set run circuits with auxiliary fuel pump de-energized. START – energizes engine starter and flashes generator field.
9	FREQUENCY ADJUST Switch	Momentary-action toggle switch. Adjusts frequency output of generator set for each activation of the switch. Works in both directions to increase and decrease output frequency.
10	AC CIRCUIT INTERRUPT Switch	Opens and closes AC Circuit Interrupt Relay. Used during parallel operation.
11	VOLTAGE ADJUST Switch	Momentary-action toggle switch. Adjusts voltage output of generator set. Works in both directions to increase and decrease output voltage.
12	FAULT RESET Switch	Resets (turns off) fault indicators displayed on Computer Interface Module display screen. Will re-energize governor power.
13	MASTER CONTROL Switch	When placed in ON position, provides battery power to DCS. Should be first switch activated on panel. Generator set cannot be started unless switch is activated.
14	GROUND FAULT CIRCUIT INTERRUPTER TEST Switch	Tests GROUND FAULT CIRCUIT INTERRUPTER.
15	GROUND FAULT CIRCUIT INTERRUPTER RESET Switch	Resets GROUND FAULT CIRCUIT INTERRUPTER.
16	Keypad Up Arrow Pushbutton ↑	Moves cursor on CIM display screen in upward direction until released.
17	Keypad Right Arrow Pushbutton →	Moves cursor on CIM display screen to the right until released.
18	Keypad SELECT Pushbutton	When pressed, selects item on CIM display screen indicated by cursor.
19	Keypad Down Arrow Pushbutton ↓	Moves cursor on CIM display screen in downward direction until released.

TABLE 2-1. DCS CONTROLS AND INDICATORS (continued)


KEY	CONTROL OR INDICATOR	FUNCTION
20	Keypad Left Arrow Pushbutton ←	Moves cursor on CIM display screen to the left until released.
21	DC CONTROL POWER Fuse	Provides overcurrent protection for DC circuits.
22	FREQUENCY SELECT Switch (MEP-806B only)	Allows selection of 50 Hz or 60 Hz.
23	REACTIVE CURRENT ADJUST rheostat	Adjusts voltage droop when two generator sets are operated in parallel.
24	VOLTAGE SCALE Switch	Reports configuration of output voltage connection selected on voltage reconnection terminal board.

2.3 COMPUTER INTERFACE MODULE (CIM) DISPLAY SCREEN CONTROLS AND INDICATORS.

The Computer Interface Module (CIM) Display Screen displays most of the indicators for the generator set. Figure 2-2 shows the CIM display screen layout. Table 2-2 describes each control and indicator. Table 2-3 describes faults that may be displayed in the FAULT INDICATOR section of the CIM display screen and related operator messages that may be displayed in the MESSAGES section.



FULL DISPLAY MODE



MAIN DISPLAY MODE

FIGURE 2-2. CIM DISPLAY SCREEN CONTROLS AND INDICATORS

TABLE 2-2. CIM DISPLAY SCREEN CONTROLS AND INDICATORS

KEY	CONTROL OR INDICATOR	FUNCTION
1	GEN VOLTAGE indicators	Indicates generator output voltage for each of the three phases.
2	BATTERY VDC indicator	Indicates charge status of both generator set DC batteries (VDC).
3	GEN CURRENT indicators	Indicates generator output current (amps) for each of the three phases.
4	FAULT INDICATOR display	Displays fault indications as they occur. Specific warnings and instructions related to a fault are displayed simultaneously in the MESSAGES display. See Table 2-3 for the list of possible faults.
5	DELTA VAC gage	Indicates generator set output voltage versus bus voltage. Used prior to operating in parallel with another unit. Used to monitor system prior to parallel operation to ensure generator and bus voltage are balanced within 5 volts before closing contactor to bus.
6	MESSAGES display	Displays warnings and instructions in the form of operator messages related to faults displayed in FAULT INDICATOR display.
7	WATER TEMP virtual meter	Indicates generator set cooling system water temperature (°F).
8	BATTLE SHORT CIRCUIT status indicator	Indicates whether generator set is in battle short mode or not. ON indication means battle short circuit is energized.
9	CONTACTOR POSITION status indicator	Indicates whether contactor is open or closed.
10	DISPLAY MODE <u>FULL</u> / <u>MAIN</u> switch	When <u>FULL</u> / <u>MAIN</u> button is selected with the keypad, CIM display screen toggles between FULL and MAIN modes and button changes to show name of mode currently displayed.
11	SHUTDOWN COMPUTER <u>EXIT</u> button	When <u>EXIT</u> button is selected with the keypad, the DCS software shuts down so the CIM can be safely deactivated. This will also shut down the generator set if it is running.
12	BATTERY AMPS virtual meter	Indicates input current of generator set DC batteries (amps).
13	OIL PRESSURE virtual meter	Indicates engine oil pressure (psi).
14	BUS VOLTAGE indicators	Indicate voltage on output bus. The GEN VOLTAGE and BUS VOLTAGE indicators must match within five volts, each phase, to perform paralleling operation.
15	VOLTAGE gage	Indicates generator set voltage output (VAC).
16	FREQ gage	Indicates generator set frequency output (Hz).
17	POWER gage	Indicates generator set power output (kW).
18	FUEL LEVEL gage	Indicates amount of fuel in fuel tank (percent remaining).

NOTES

TABLE 2-3. FAULTS

NOTE: Maintainers can only check faults at their level.

FAULT	MESSAGE #	MESSAGE
CIRCUIT FAILURE - FUEL LEVEL	01	The fuel level signal is lower than the operating range. Check fuel level. Check fuel sensor and circuit. (Para. 4.11.5)
SHUTDOWN - LOW FUEL	02	Fuel level is abnormally low. Check fuel level. Verify fuel system lineup.
WARNING - LOW FUEL	03	Fuel level is abnormally low. Check fuel level. Verify fuel system lineup.
CIRCUIT FAILURE - FUEL LEVEL	04	The fuel level signal is higher than the operating range. Check fuel level. Check fuel sensor and circuit. (Para. 4.11.5)
CIRCUIT FAILURE - COOLANT TEMP	05	The coolant temperature signal is lower than the operating range. Check coolant level. Check coolant temperature sensor and circuit. (Para. 4.13.2)
	06	The coolant temperature is higher than the operating range. Check coolant level. Check coolant temperature sensor and circuit. (Para. 4.13.2)
WARNING - COOLANT TEMP	07	Coolant temperature is abnormally high. Check coolant level. Verify coolant system lineup. (Para. 3.3.5)
SHUTDOWN - COOLANT TEMP	08	Coolant temperature is abnormally high. Check coolant level. Verify coolant system lineup. (Para. 3.3.5)
CIRCUIT FAILURE - OIL PRESSURE	09	The oil pressure signal is lower than the operating range. Check oil pressure. Check oil pressure sensor and circuit. (Para. 4.13.1)
	10	The oil pressure signal is higher than the operating range. Check oil pressure. Check oil pressure sensor and circuit. (Para. 4.13.1)
WARNING - LOW OIL	11	Oil pressure is abnormally low. Check oil. Verify lubricating system lineup. (Para. 3.3.8)
SHUTDOWN - LOW OIL	12	Oil pressure is abnormally low. Check oil. Verify lubricating system lineup. (Para. 3.3.8)
WARNING - OVERVOLTAGE	13	Generator voltage is abnormally high. Adjust VOLTAGE ADJUST switch. (Para. 2.11.1 j)
SHUTDOWN - OVERVOLTAGE	14	Generator voltage is abnormally high. Adjust VOLTAGE ADJUST switch. (Para. 2.11.1 j)
WARNING - OVERSPEED	15	Generator frequency is abnormally high. Adjust FREQUENCY ADJUST switch. (Para. 2.11.1 j)
SHUTDOWN - OVERSPEED	16	Generator frequency is abnormally high. Adjust FREQUENCY ADJUST switch. (Para. 2.11.1 j)
WARNING - UNDERVOLTAGE	17	Generator voltage is abnormally low. Adjust VOLTAGE ADJUST switch. (Para. 2.11.1 j)
CONTACTOR TRIP - UNDERVOLTAGE	18	Generator voltage is abnormally low. Adjust VOLTAGE ADJUST switch. (Para. 2.11.1 j)
WARNING - OVERLOAD	19	System load is abnormally high. Reduce load to within generator set ratings. (Para. 2.11.1 n and o)

TABLE 2-3. FAULTS (continued)

FAULT	MESSAGE #	MESSAGE
CONTACTOR TRIP - OVERLOAD	20	System load is abnormally high. Reduce load to within generator set ratings. (Para. 2.12)
CONTACTOR TRIP - REVERSE POWER	21	Load share device sensed reverse power conditions. Verify load share device setpoints are correct.
CONTACTOR TRIP - SHORT CIRCUIT	22	System load was abnormally high. Reduce load to within generator set ratings.

2.4 DIAGNOSTIC CONTROLS AND INDICATORS.

The DCS load sharing synchronizer, DCS speed control unit, automatic voltage regulator, backplane module, and I/O interface module are equipped with indicators used as diagnostic tools in troubleshooting. Some of the DCS modules also include controls that are set at installation and may need to be adjusted during troubleshooting. Figure 2-3 shows the locations of the controls and indicators on the DCS modules. Table 2-4 describes each control and indicator.




FIGURE 2-3. DIAGNOSTIC CONTROLS AND INDICATORS (SHEET 1 OF 2)




FIGURE 2-3. DIAGNOSTIC CONTROLS AND INDICATORS (SHEET 2 OF 2)

TABLE 2-4. DIAGNOSTIC CONTROLS AND INDICATORS

KEY	CONTROL OR INDICATOR	FUNCTION
DCS LOAD SHARING SYNCHRONIZER		
1	L1 indicator (green LED)	This indicator is lit when the load sharing control is making transition from zero power output up to a power output in a load sharing (paralleling) condition. Normally, this LED is lit only during the load sharing (paralleling) period.
2	L2 indicator (green LED)	This indicator is lit only when zero power from the generator set is reached before the breaker is opened. It indicates when the I/O interface module is calling for the generator to go to zero power output before the generator breaker is opened automatically by the I/O interface module.
3	REVERSE POWER (red LED)	This indicator is lit when a reverse power situation exists. The I/O interface module has been notified to remove the generator set from service (open the breaker).
4	GEN indicator (green LED)	This indicator is normally lit when the generator set is operating (engine is running). When lit, the LED indicates the module is receiving AC power from the generator.
5	BUS indicator (green LED)	This indicator is normally lit only when the generator set is running and the main breaker is closed. It is also lit when another generator set is connected to the main breaker and its breaker is closed. When lit, the LED indicates AC power is being received from the bus (the output of the generator set main breaker) into the module. The indicator is not lit if the bus has failed, and when this module is not being used.
6	SYNCH ENABLED indicator (green LED)	This indicator is lit only when the I/O interface module requests synchronizing the output power of the generator set with a second generator set and the paralleling cable has been connected between the two sets. In addition, the AC CIRCUIT INTERRUPT switch on the primary set has been previously moved to the CLOSED position. This indicator is lit only during the synchronizing period.
7	PARALLEL ENABLE indicator (green LED)	This indicator will be lit when the I/O interface module has closed the main breaker. That is, the I/O interface module has commanded the DCS load sharing synchronizer to close the connection with the paralleling cable and begin parallel operation of the two generator sets.
8	SYNCHRONIZED indicator (green LED)	This indicator will be lit when the generator is in synch with the bus. When this LED is lit, the DCS load sharing synchronizer has signaled the I/O interface module that paralleling may occur.
9	DC POWER indicator (green LED)	This indicator is normally lit only when the generator set is operating (engine is running). It is off at all other times. When lit, the LED indicates the internal DC supply of the module is operating (i.e., the module is receiving DC power from the generator set, and the module is properly converting the power into its own operating voltage(s).

TABLE 2-4. DIAGNOSTIC CONTROLS AND INDICATORS (continued)

KEY	CONTROL OR INDICATOR	FUNCTION
SPEED CONTROL UNIT		
10	OVERSPEED indicator (red LED)	This indicator is normally off, even when the generator set is operating. When the LED is lit, an engine overspeed condition has occurred (the flywheel RPM sensor has sent the speed control unit a value which is defined as out-of-tolerance). The indicator will remain lit until either of two events has occurred: (1) The OVERSPEED RESET pushbutton has been manually activated, or (2) the generator set (engine) has been stopped and the DC power is reset.
11	ACTUATOR indicator (green LED)	This indicator is normally lit when the electric actuator (on the injection fuel pump) has power applied to it. The LED will be lit when the engine is operating or when the engine is being cranked (started). If the indicator is off while the engine is operating, it can mean: (1) the electric actuator has failed, (2) the connection between the actuator and the module has failed, or (3) the module has malfunctioned or failed.
12	SPEED SENSOR indicator (green LED)	This indicator is normally lit when the engine is operating. The indicator lit/off function is directly related to the signal from the speed sensor connected to the flywheel. If the indicator is off, but the engine is operating, this indicates the engine RPM signal is not being received. This can be caused by sensor failure or by a failure in the connection to the sensor.
13	OVERSPEED RESET pushbutton	If the OVERSPEED indicator is lit and the engine has stopped, this switch may be used to attempt to reset the overspeed protection system. If the OVERSPEED indicator turns off when the switch is activated, the protection system is reset, and the engine may be restarted. (The conclusion is that no problem exists with engine speed.) If after restarting the OVERSPEED indicator comes on again and the engine stops, there is a problem with engine speed control.
14	OVERSPEED TEST pushbutton	This switch is used to test one of the protective systems of the generator set: engine overspeed protection. Pressing this switch while the engine is running at rated speed will activate the overspeed protection system, thereby stopping the engine.
15	DC POWER indicator (green LED)	This indicator is normally lit when the engine is operating. It indicates the internal DC power in the module is operating.
16	CRANK TERMINATION (green LED)	This indicator is normally lit when the engine is operating. When the engine is being started, the indicator will remain off until engine speed exceeds 900 RPM and the cranking relay returns to its normal (non-energized) state. If the indicator remains off and the engine starter continues operation, this is an indication of a failure in the starter assembly or of the cranking relay.
BACKPLANE MODULE		
17	LED 16 (red) indicator	(not assigned)
18	LED 15 (red) indicator	(not assigned)
19	LED 14 (red) indicator	Fault indication. If indicator is lit, indicates a fault has occurred. If off, indicates normal running condition.



TABLE 2-4. DIAGNOSTIC CONTROLS AND INDICATORS (continued)

KEY	CONTROL OR INDICATOR	FUNCTION
BACKPLANE MODULE (continued)		
20	LED 13 (red) indicator	Short circuit indication. If indicator is lit, indicates a short circuit condition affecting generator set output has been detected.
21	LED 12 (green)	(not assigned)
22	LED 11 (green)	Remote display connection. Indicator blinks on and off when remote display is properly connected. If not lit, indicates no remote display connection has been made.
23	LED 10 (green)	Data validity from remote display. Indicator blinks on and off to indicate remote data is being received properly. If not lit, remote data is not being received properly. If not lit, can also indicate no remote display function has been connected.
24	LED 9 (green)	Status of the main generator power bus. If indicator is lit, the bus is energized (voltage is present), and voltage is available for paralleling operation. If not lit, indicates the generator set is operating in a stand-alone mode.
25	LED 8 (red)	(not assigned)
26	LED 7 (red)	Network failure. If indicator is lit, indicates the CIM is not communicating with the I/O interface module. If not lit, indicates the CIM is communicating properly.
27	LED 6 (red)	Emergency stop. If indicator is lit, indicates the EMERGENCY STOP switch has been activated. If not lit, indicates normal running condition.
28	LED 5 (red)	CMOS voltage. If indicator is lit, indicates voltage necessary for CMOS device operation is ^{SUFFICIENT} too low. If not lit, CMOS device voltage source is ^{TOO LOW} sufficient.
29	LED 4 (green)	(not assigned)
30	LED 3 (green)	Heartbeat. If indicator is blinking on and off, indicates proper operation of this module. If not lit, indicates module has no power applied or has failed.
31	LED 2 (green)	(not assigned)
32	LED 1 (green)	If indicator is lit, fuel pump is operating. If not lit, fuel pump is not operating.
AUTOMATIC VOLTAGE REGULATOR		
33	AC SENSING (green LED)	This indicator is normally lit, indicating the AC sensor is sending the proper signal to this module.
34	DC SUPPLY indicator (green LED)	This indicator is normally lit, indicating that the module's internal DC supply is operating. The source for input power to this module is the AC output of the generator set. Therefore, the indicator will not be lit until the generator set is providing power output to a load.
35	FIELD VOLTAGE (green LED)	This indicator is normally lit. It indicates field voltage is present, which means the generator is developing AC power.

TABLE 2-4. DIAGNOSTIC CONTROLS AND INDICATORS (continued)

KEY	CONTROL OR INDICATOR	FUNCTION
I/O INTERFACE MODULE		
36	HEARTBEAT (green LED)	This indicator is normally blinking on and off when DC power has been applied to the module. It is also normally blinking when the generator set is operating (engine running) and the module is functioning properly. If the indicator is either steady-state lit or steady-state off, but the CIM has been turned on and the engine is operating, this is an indication that there is a problem in the I/O interface module.
37	DIP Switch Assembly (8 positions)	These switches define the configuration of the generator set for the CIM. The generator set configuration is defined in two ways: its output power (kW) rating and its frequency rating. These switches must be set to a specified configuration prior to the module's use in the generator set. Unless these switches are properly set (and remain so), the generator set can experience a malfunction. For the MEP-806B, all switches are set to OFF. For the MEP-816B, Switch 5 is set to ON and all the other switches to OFF. (Ref Figure 4-31)

SCHEMATIC DIAGRAM



POSITION	CIRCUIT SCHEDULE
1 - OFF	4-6-8 JUMPERED
2 - PRIME & RUN	3-4-5-6-8
3 - AUX. FUEL	3-4-6-8
4 - START	3-4-6-7-8

- A1 BACKPLANE SYNCHRONIZER
- A2 LOAD SHARE SYNCHRONIZER
- A3 SPEED CONTROL UNIT
- A4 VOLTAGE REGULATOR
- A5 I/O MODULE
- A6 SPEED CONTROL ACTUATOR
- A10-13 STARTER
- B1 BATTERY CURRENT TRANSFORMER
- B2 BATTERY 12V
- B3 GND FAULT CIRCUIT PROTECTOR
- B4 COMPUTER INTERFACE MODULE
- B5 DS1
- B6 DS2
- B7 DS3
- B8 DS5
- B9 ET
- C1 CR10
- C2 CR11
- C3 CR12
- C4 CR13
- C5 CR14
- C6 CR15
- C7 CR16
- C8 CR17
- C9 CR18
- C10 CR19
- C11 CR20
- C12 CR21
- C13 CR22
- C14 CR23
- C15 CR24
- C16 CR25
- C17 CR26
- C18 CR27
- C19 CR28
- C20 CR29
- C21 CR30
- C22 CR31
- C23 CR32
- C24 CR33
- C25 CR34
- C26 CR35
- C27 CR36
- C28 CR37
- C29 CR38
- C30 CR39
- C31 CR40
- C32 CR41
- C33 CR42
- C34 CR43
- C35 CR44
- C36 CR45
- C37 CR46
- C38 CR47
- C39 CR48
- C40 CR49
- C41 CR50
- C42 CR51
- C43 CR52
- C44 CR53
- C45 CR54
- C46 CR55
- C47 CR56
- C48 CR57
- C49 CR58
- C50 CR59
- C51 CR60
- C52 CR61
- C53 CR62
- C54 CR63
- C55 CR64
- C56 CR65
- C57 CR66
- C58 CR67
- C59 CR68
- C60 CR69
- C61 CR70
- C62 CR71
- C63 CR72
- C64 CR73
- C65 CR74
- C66 CR75
- C67 CR76
- C68 CR77
- C69 CR78
- C70 CR79
- C71 CR80
- C72 CR81
- C73 CR82
- C74 CR83
- C75 CR84
- C76 CR85
- C77 CR86
- C78 CR87
- C79 CR88
- C80 CR89
- C81 CR90
- C82 CR91
- C83 CR92
- C84 CR93
- C85 CR94
- C86 CR95
- C87 CR96
- C88 CR97
- C89 CR98
- C90 CR99
- C91 CR100
- C92 CR101
- C93 CR102
- C94 CR103
- C95 CR104
- C96 CR105
- C97 CR106
- C98 CR107
- C99 CR108
- C100 CR109
- C101 CR110
- C102 CR111
- C103 CR112
- C104 CR113
- C105 CR114
- C106 CR115
- C107 CR116
- C108 CR117
- C109 CR118
- C110 CR119
- C111 CR120
- C112 CR121
- C113 CR122
- C114 CR123
- C115 CR124
- C116 CR125
- C117 CR126
- C118 CR127
- C119 CR128
- C120 CR129
- C121 CR130
- C122 CR131
- C123 CR132
- C124 CR133
- C125 CR134
- C126 CR135
- C127 CR136
- C128 CR137
- C129 CR138
- C130 CR139
- C131 CR140
- C132 CR141
- C133 CR142
- C134 CR143
- C135 CR144
- C136 CR145
- C137 CR146
- C138 CR147
- C139 CR148
- C140 CR149
- C141 CR150
- C142 CR151
- C143 CR152
- C144 CR153
- C145 CR154
- C146 CR155
- C147 CR156
- C148 CR157
- C149 CR158
- C150 CR159
- C151 CR160
- C152 CR161
- C153 CR162
- C154 CR163
- C155 CR164
- C156 CR165
- C157 CR166
- C158 CR167
- C159 CR168
- C160 CR169
- C161 CR170
- C162 CR171
- C163 CR172
- C164 CR173
- C165 CR174
- C166 CR175
- C167 CR176
- C168 CR177
- C169 CR178
- C170 CR179
- C171 CR180
- C172 CR181
- C173 CR182
- C174 CR183
- C175 CR184
- C176 CR185
- C177 CR186
- C178 CR187
- C179 CR188
- C180 CR189
- C181 CR190
- C182 CR191
- C183 CR192
- C184 CR193
- C185 CR194
- C186 CR195
- C187 CR196
- C188 CR197
- C189 CR198
- C190 CR199
- C191 CR200
- C192 CR201
- C193 CR202
- C194 CR203
- C195 CR204
- C196 CR205
- C197 CR206
- C198 CR207
- C199 CR208
- C200 CR209
- C201 CR210
- C202 CR211
- C203 CR212
- C204 CR213
- C205 CR214
- C206 CR215
- C207 CR216
- C208 CR217
- C209 CR218
- C210 CR219
- C211 CR220
- C212 CR221
- C213 CR222
- C214 CR223
- C215 CR224
- C216 CR225
- C217 CR226
- C218 CR227
- C219 CR228
- C220 CR229
- C221 CR230
- C222 CR231
- C223 CR232
- C224 CR233
- C225 CR234
- C226 CR235
- C227 CR236
- C228 CR237
- C229 CR238
- C230 CR239
- C231 CR240
- C232 CR241
- C233 CR242
- C234 CR243
- C235 CR244
- C236 CR245
- C237 CR246
- C238 CR247
- C239 CR248
- C240 CR249
- C241 CR250
- C242 CR251
- C243 CR252
- C244 CR253
- C245 CR254
- C246 CR255
- C247 CR256
- C248 CR257
- C249 CR258
- C250 CR259
- C251 CR260
- C252 CR261
- C253 CR262
- C254 CR263
- C255 CR264
- C256 CR265
- C257 CR266
- C258 CR267
- C259 CR268
- C260 CR269
- C261 CR270
- C262 CR271
- C263 CR272
- C264 CR273
- C265 CR274
- C266 CR275
- C267 CR276
- C268 CR277
- C269 CR278
- C270 CR279
- C271 CR280
- C272 CR281
- C273 CR282
- C274 CR283
- C275 CR284
- C276 CR285
- C277 CR286
- C278 CR287
- C279 CR288
- C280 CR289
- C281 CR290
- C282 CR291
- C283 CR292
- C284 CR293
- C285 CR294
- C286 CR295
- C287 CR296
- C288 CR297
- C289 CR298
- C290 CR299
- C291 CR300
- C292 CR301
- C293 CR302
- C294 CR303
- C295 CR304
- C296 CR305
- C297 CR306
- C298 CR307
- C299 CR308
- C300 CR309
- C301 CR310
- C302 CR311
- C303 CR312
- C304 CR313
- C305 CR314
- C306 CR315
- C307 CR316
- C308 CR317
- C309 CR318
- C310 CR319
- C311 CR320
- C312 CR321
- C313 CR322
- C314 CR323
- C315 CR324
- C316 CR325
- C317 CR326
- C318 CR327
- C319 CR328
- C320 CR329
- C321 CR330
- C322 CR331
- C323 CR332
- C324 CR333
- C325 CR334
- C326 CR335
- C327 CR336
- C328 CR337
- C329 CR338
- C330 CR339
- C331 CR340
- C332 CR341
- C333 CR342
- C334 CR343
- C335 CR344
- C336 CR345
- C337 CR346
- C338 CR347
- C339 CR348
- C340 CR349
- C341 CR350
- C342 CR351
- C343 CR352
- C344 CR353
- C345 CR354
- C346 CR355
- C347 CR356
- C348 CR357
- C349 CR358
- C350 CR359
- C351 CR360
- C352 CR361
- C353 CR362
- C354 CR363
- C355 CR364
- C356 CR365
- C357 CR366
- C358 CR367
- C359 CR368
- C360 CR369
- C361 CR370
- C362 CR371
- C363 CR372
- C364 CR373
- C365 CR374
- C366 CR375
- C367 CR376
- C368 CR377
- C369 CR378
- C370 CR379
- C371 CR380
- C372 CR381
- C373 CR382
- C374 CR383
- C375 CR384
- C376 CR385
- C377 CR386
- C378 CR387
- C379 CR388
- C380 CR389
- C381 CR390
- C382 CR391
- C383 CR392
- C384 CR393
- C385 CR394
- C386 CR395
- C387 CR396
- C388 CR397
- C389 CR398
- C390 CR399
- C391 CR400
- C392 CR401
- C393 CR402
- C394 CR403
- C395 CR404
- C396 CR405
- C397 CR406
- C398 CR407
- C399 CR408
- C400 CR409
- C401 CR410
- C402 CR411
- C403 CR412
- C404 CR413
- C405 CR414
- C406 CR415
- C407 CR416
- C408 CR417
- C409 CR418
- C410 CR419
- C411 CR420
- C412 CR421
- C413 CR422
- C414 CR423
- C415 CR424
- C416 CR425
- C417 CR426
- C418 CR427
- C419 CR428
- C420 CR429
- C421 CR430
- C422 CR431
- C423 CR432
- C424 CR433
- C425 CR434
- C426 CR435
- C427 CR436
- C428 CR437
- C429 CR438
- C430 CR439
- C431 CR440
- C432 CR441
- C433 CR442
- C434 CR443
- C435 CR444
- C436 CR445
- C437 CR446
- C438 CR447
- C439 CR448
- C440 CR449
- C441 CR450
- C442 CR451
- C443 CR452
- C444 CR453
- C445 CR454
- C446 CR455
- C447 CR456
- C448 CR457
- C449 CR458
- C450 CR459
- C451 CR460
- C452 CR461
- C453 CR462
- C454 CR463
- C455 CR464
- C456 CR465
- C457 CR466
- C458 CR467
- C459 CR468
- C460 CR469
- C461 CR470
- C462 CR471
- C463 CR472
- C464 CR473
- C465 CR474
- C466 CR475
- C467 CR476
- C468 CR477
- C469 CR478
- C470 CR479
- C471 CR480
- C472 CR481
- C473 CR482
- C474 CR483
- C475 CR484
- C476 CR485
- C477 CR486
- C478 CR487
- C479 CR488
- C480 CR489
- C481 CR490
- C482 CR491
- C483 CR492
- C484 CR493
- C485 CR494
- C486 CR495
- C487 CR496
- C488 CR497
- C489 CR498
- C490 CR499
- C491 CR500
- C492 CR501
- C493 CR502
- C494 CR503
- C495 CR504
- C496 CR505
- C497 CR506
- C498 CR507
- C499 CR508
- C500 CR509
- C501 CR510
- C502 CR511
- C503 CR512
- C504 CR513
- C505 CR514
- C506 CR515
- C507 CR516
- C508 CR517
- C509 CR518
- C510 CR519
- C511 CR520
- C512 CR521
- C513 CR522
- C514 CR523
- C515 CR524
- C516 CR525
- C517 CR526
- C518 CR527
- C519 CR528
- C520 CR529
- C521 CR530
- C522 CR531
- C523 CR532
- C524 CR533
- C525 CR534
- C526 CR535
- C527 CR536
- C528 CR537
- C529 CR538
- C530 CR539
- C531 CR540
- C532 CR541
- C533 CR542
- C534 CR543
- C535 CR544
- C536 CR545
- C537 CR546
- C538 CR547
- C539 CR548
- C540 CR549
- C541 CR550
- C542 CR551
- C543 CR552
- C544 CR553
- C545 CR554
- C546 CR555
- C547 CR556
- C548 CR557
- C549 CR558
- C550 CR559
- C551 CR560
- C552 CR561
- C553 CR562
- C554 CR563
- C555 CR564
- C556 CR565
- C557 CR566
- C558 CR567
- C559 CR568
- C560 CR569
- C561 CR570
- C562 CR571
- C563 CR572
- C564 CR573
- C565 CR574
- C566 CR575
- C567 CR576
- C568 CR577
- C569 CR578
- C570 CR579
- C571 CR580
- C572 CR581
- C573 CR582
- C574 CR583
- C575 CR584
- C576 CR585
- C577 CR586
- C578 CR587
- C579 CR588
- C580 CR589
- C581 CR590
- C582 CR591
- C583 CR592
- C584 CR593
- C585 CR594
- C586 CR595
- C587 CR596
- C588 CR597
- C589 CR598
- C590 CR599
- C591 CR600
- C592 CR601
- C593 CR602
- C594 CR603
- C595 CR604
- C596 CR605
- C597 CR606
- C598 CR607
- C599 CR608
- C600 CR609
- C601 CR610
- C602 CR611
- C603 CR612
- C604 CR613
- C605 CR614
- C606 CR615
- C607 CR616
- C608 CR617
- C609 CR618
- C610 CR619
- C611 CR620
- C612 CR621
- C613 CR622
- C614 CR623
- C615 CR624
- C616 CR625
- C617 CR626
- C618 CR627
- C619 CR628
- C620 CR629
- C621 CR630
- C622 CR631
- C623 CR632
- C624 CR633
- C625 CR634
- C626 CR635
- C627 CR636
- C628 CR637
- C629 CR638
- C630 CR639
- C631 CR640
- C632 CR641
- C633 CR642
- C634 CR643
- C635 CR644
- C636 CR645
- C637 CR646
- C638 CR647
- C639 CR648
- C640 CR649
- C641 CR650
- C642 CR651
- C643 CR652
- C644 CR653
- C645 CR654
- C646 CR655
- C647 CR656
- C648 CR657
- C649 CR658
- C650 CR659
- C651 CR660
- C652 CR661
- C653 CR662
- C654 CR663
- C655 CR664
- C656 CR665
- C657 CR666
- C658 CR667
- C659 CR668
- C660 CR669
- C661 CR670
- C662 CR671
- C663 CR672
- C664 CR673
- C665 CR674
- C666 CR675
- C667 CR676
- C668 CR677
- C669 CR678
- C670 CR679
- C671 CR680
- C672 CR681
- C673 CR682
- C674 CR683
- C675 CR684
- C676 CR685
- C677 CR686
- C678 CR687
- C679 CR688
- C680 CR689
- C681 CR690
- C682 CR691
- C683 CR692
- C684 CR693
- C685 CR694
- C686 CR695
- C687 CR696
- C688 CR697
- C689 CR698
- C690 CR699
- C691 CR700
- C692 CR701
- C693 CR702
- C694 CR703
- C695 CR704
- C696 CR705
- C697 CR706
- C698 CR707
- C699 CR708
- C700 CR709
- C701 CR710
- C702 CR711
- C703 CR712
- C704 CR713
- C705 CR714
- C706 CR715
- C707 CR716
- C708 CR717
- C709 CR718
- C710 CR719
- C711 CR720
- C712 CR721
- C713 CR722
- C714 CR723
- C715 CR724
- C716 CR725
- C717 CR726
- C718 CR727
- C719 CR728
- C720 CR729
- C721 CR730
- C722 CR731
- C723 CR732
- C724 CR733
- C72

WIRING DIAGRAM

- A1 BACKPLANE
- A2 LOAD SHARE SYNCHRONIZER
- A3 SPEED CONTROL UNIT
- A4 VOLTAGE REGULATOR
- A5 I/O MODULE
- A6 SPEED CONTROL ACTUATOR
- A10-13 EMI FILTER
- B1 STARTER
- BCT BATTERY CURRENT TRANSFORMER
- BT1-2 BATTERY 12V
- CB3 GND FAULT CIRCUIT PROTECTOR
- CIM COMPUTER INTERFACE MODULE
- CR1 REVERSE BATTERY DIODE
- CR2 FIELD FLASH DIODE
- CR3,4,5,7,8 BLOCKING DIODE
- CR6 SUPPRESSING DIODE
- CR9 AC INTERRUPTER AUX DIODE (30 KW GENERATOR ONLY)
- CR10 CRANKING RELAY DIODE
- CT1 CURRENT TRANSFORMER
- CT5 DROOP CURRENT TRANSFORMER

- DS1 PANEL LIGHT
- DS2 PANEL LIGHT
- DS3 PANEL LIGHT
- DSS NETWORK FAILURE LIGHT
- E1 AUXILIARY FUEL PUMP
- F1 DC CONTROL POWER FUSE
- F2 ALTERNATOR FUSE
- G1 AC GENERATOR
- G2 BATTERY CHARGING ALTERNATOR
- HTR-1 HEATER ASSEMBLY
- HTR-2 HEATER ASSEMBLY
- J1 CONVENIENCE RECEPTACLE

- J2 PARALLEL RECEPTACLE
- J3 COMMUNICATION RECEPTACLE
- J16 SWITCH BOX RECEPTACLE
- J20 SERIAL PORT #1
- J26 SERIAL PORT #2
- J29 PARALLEL PORT
- K1 AC CIRCUIT INTERRUPTER
- K2 CRANKING RELAY
- K15 START RELAY
- K17 K1 AUXILIARY RELAY

- K19 FUEL TRANSFER PUMP RELAY
- K22 LOAD/UNLOAD RELAY
- K23 FIELD FLASH RELAY
- K24 ETHER SOLENOID RELAY
- L1 OUTPUT TERMINAL
- L2 OUTPUT TERMINAL
- L3 OUTPUT TERMINAL
- L4 STARTER SOLENOID
- L6 ETHER SOLENOID VALVE

- M3 TIME METER
- MPU MAGNETIC PICKUP
- MT5 FUEL LEVEL SENDER
- MT6 COOLANT TEMPERATURE SENDER
- MT7 OIL PRESSURE SENDER
- MT8 AMBIENT TEMP SENDER
- N OUTPUT TERMINAL
- PS1 POWER SUPPLY
- P20 SERIAL PORT #1
- P27 CIM DATA
- P32 KEYPAD CONNECTOR
- R5 REACTIVE CURRENT ADJUST
- R15 LED RESISTOR
- R16-R17 VOLTAGE REGULATOR RESISTOR
- S1 MASTER SWITCH
- S2 PANEL LIGHT SWITCH
- S3 MASTER CONTROL SWITCH

- S4 FAULT RESET SWITCH
- S5 AC CIRCUIT INTERRUPTER SWITCH
- S7 BATTLE SHORT SWITCH
- S9 ETHER START ASSIST SWITCH
- S10 DEAD CRANK SWITCH
- S12 FREQUENCY SELECTOR SWITCH
- S17 EMERGENCY STOP SWITCH
- S18 VOLTAGE ADJUSTMENT SWITCH
- S19 FREQUENCY ADJUSTMENT SWITCH
- S20 VOLTAGE SELECT SWITCH
- SR1 SLAVE RECEPTACLE
- T1 POTENTIAL TRANSFORMER
- TB1 VOLTAGE RECONNECTION TERMINAL BOARD
- TB2 LOAD OUTPUT TERMINAL BOARD
- TP TCST PLUG
- V1-V4 VARISTOR AC LOAD LINES

